HAYLOU GT7

真无线蓝牙耳机

使用说明书

耳机重置:

1、耳机放回充电盒，保持充电盒电量充足，然后长按耳机MFB键10秒;
2、清除手机配对记录和TWS配对记录，然后关机，重新完成连接即可。

* 若操作不成功，请重复以上步骤；或登录官方旗舰店，联系客服，查看复位操作视频。

常见异常:

1、耳机一边有声一边无声:
尝试将无声的耳机放入充电盒再取出;
以上步骤操作后还无法解决，尝试重置步骤;
2、耳机无法充电:
检查充电舱电量是否充足;
用干布或者棉签擦拭充电接触部位;
3、耳机无法和手机自动断连:
检查充电舱电量是否充足，没电会导致耳机无法关机，无法和手机断开连接。

包装内容物

耳机、充电盒、充电线、说明书。

耳机基本参数
通讯距离：10米（无障碍空旷环境）
电池容量：35mAh（单耳机）
充电时间：约2小时
通话时间：约3小时
待机时间：约60小时
输入参数：5V⎓50mA
电池类型：锂离子聚合物电池
无线连接：蓝牙5.2

充电盒基本参数
输入参数：5V⎓300mA
输出参数：5V⎓100mA
充电时间：约2小时
电池容量：310mAh
电池类型：锂离子聚合物

日常维护
请勿佩戴耳机洗澡、淋雨，放入洗衣机及在异常温度情况等极端环境使用。每次正常使用后，请用干布等工具擦干耳机上的汗汁或者雨水，可以有效延长耳机的使用时长。

HAYLOU

HAYLOU GT7

True Wireless Earbuds

User Manual

Overview

How to Wear

Gently insert the earbud into the ear canal, adjust the earbud to the most comfortable wearing state.

When calling, adjust Mic towards mouth to gain better talking experience.

How to Charge

For first time use, please remove the isolation film on the charging contacts of both earbuds. Then fully charge the charging case and earbuds.



Plug in the charging cable to charge the earbuds and the charging case at the same time. The charging indicator light will be solid white when the charging case is not fully charged. The indicator light goes out after fully charged.

Power-on

1. Take out to auto power on when the earbuds are in case.
2. If earbuds are out of case and in power-off state, keep touching the MFB button for about 1.5s to power on.

Power-off

1. The earbuds will auto power off when put in the charging case.
2. Keep touching the MFB button for 4.5s to power off.

How to Pair

Take two earbuds out from the charging case simultaneously, then open device Bluetooth and search for "Haylou GT7", finally click it to complete the connection.
Put the earbuds back to the charging case and repeat the above operation if the connection fails. After the first connection, the earbuds can be automatically connected to the last paired device (Bluetooth needs to be turned on).

Switch between mono and stereo mode: It is stereo mode after two earbuds are successfully connected. Put one back into the case to power off, the other will enter mono mode. Or pick it up again to resume stereo mode.

Manual connection: when earbuds are turned off, manually turn on both of them. Wait 2-3 seconds for them to turn on and connect to each other. Turn on device Bluetooth to connect when light on single earbud flashes white slowly.

Functions



Short touch MFB button
Play/pause music
Double touch right MFB button
Skip track forward
Short touch MFB button
Answer/hang up
Triple touch MFB button
Activate voice assistant
Double touch left MFB button
Turn on/off low latency mode

Answer the Second Call
When there is a new incoming call during a call, short touch the MFB button to hold the previous call and answer the second call, then double touch the MFB button to switch the call, hold the current call, switch to the previous call, and then short touch the MFB button to hang up the current call and answer the call on hold.

Factory Setting

1. Put the earbuds back into the charging case and keep the charging case fully charged. Then long touch the earbuds MFB buttons for 10s;
2. Clear phone pairing record and TWS pairing record, then turn off, and complete the connection again.

Common abnormals:

1. One of the earbuds is mute:
Try to put the mute earbud into the charging case and then take it out;
If the problem is still not solved after the above operation, try the reset steps;
2. The earbud cannot be charged:
Check whether the charging case has sufficient power;
Wipe the charging contacts with a dry cloth or cotton swab;
3. The earbud cannot automatically disconnect from the mobile phone;
Check whether the charging case has sufficient power. The earbud will not power off if the case is out of power and will not disconnect from the mobile phone.

Package List

Earbuds, charging case, charging cable, user manual.

Basic Parameters(earbuds)
Operation range: 10m (open space with no obstacle)
Battery capacity: 35mAh(single earbud)
Charging time: approx. 2hr
Talk time: approx. 3hr
Standby time: approx. 60hr
Input parameter: 5V ⎓ 50mA
Battery type: li-ion
Bluetooth version: V5.2

Basic Parameters(charging case)
Input parameter: 5V ⎓ 300mA
Output parameter: 5V ⎓ 100mA
Charging time: approx. 2hr
Battery capacity: 310mAh
Battery type: li-ion

CE UKCA FC FCC ID: 2A8Q6-GT7

Caveats

Warning

1. Do not disassemble, repair or modify the product for any reason, as this may cause fire or even completely destroy the product.
2. Do not expose the product to environments where the temperature is too low or too high (below 0°C or above 45°C).
3. Keep the indicators away from the eyes of children and animals while using the earphones.
4. Do not use this product during thunderstorms. Thunderstorms may cause the product to malfunction and increase the risk of electric shocks.
5. Do not wipe and clean the earphones or their case with alcohol or other volatile liquids.
6. Avoid any contact with liquids.

Note

1. Please read this user manual carefully before using the product and please properly store it.
2. When using for the first time, please fully charge this product.
3. Please charge the product, in case it has not been used over two weeks.

4. Please use certificated charger.
5. Do not wear earphones for a long term to protect your hearing.
6. Do not wear earphones in any situations with potential risks as wearing them may reduce your perception to the outside world.

FCC Requirement
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
1. This device may not cause harmful interference;
2. This device must accept any interference received, including interference that may cause undesired operation.

Daily maintenance
Please do not shower with earbuds. Do not wear them in rainy day. Do not leave them in washing machine or other extreme situations. Clean them with dry cloth.

Warranty Card

Warranty Period
12 months after you purchase this item.
(or you may inquire your local shopper for more details.)

Free Service
Supposing any defects caused by quality issues occur within the warranty period, please take this warranty card and purchase receipts to your distributor for free exchange service.

Model Number	
Date of Purchasing	
User's Name	
User's Phone	
User's Address	
Shop's Name	
Shop's Address	
Comments	

Free exchange service will not be accessed under following circumstances:
1. Damages caused by unauthorized disassembly.
2. Defects or physical damages caused by leaking or dropping off.
3. Damages caused by act of God.
Supposing your item is within any damages or defects except the above circumstances, please return to us or your distributor for free repairing.

Manufacturer: Dongguan Liesheng Electronic Co., Ltd.
Address: Room 401-410, Building 1, No. 86 Hongtu Road, Nancheng District, Dongguan City, Guangdong, China