TCL

ALTO 3
## 2.0 Channel Sound Bar with Dolby Audio

Quick Start Guide

1 What's in the box

Make sure you read all the safety information before you use this product.

**Sound Bar main unit**

AC power cord

Optical cable

Remote control

AAA battery x 2

Safety instructions

Safety leaflet

Warranty card

Warranty card

QSG

Quick Start Guide

2a Overview

Sound Bar main unit

Power button:
Short press to power on/off. Long press to reset to factory default

Source button:
Press to switch the audio source among AUX/BT/OPT/USB modes.

Volume buttons:
Press to increase or decrease the volume level.

TCL

2b Overview

1. **USB Type A connector**
2. **AUX input connector**
3. **Optical input connector**
4. **AC input power connector**

USB	AUX	OPTICAL	~AC IN
❶	❷	❸	❹

3 | Place your Sound Bar

The ideal place to position the Sound Bar is centered underneath your TV.

TV

4a | Optical

There are 2 ways to connect your sound bar to the TV (listed in order that we recommend): Optical and AUX (refer to 4b).

Connect the Sound Bar with your TV through the supplied Optical cable.

Connect the Sound Bar to the power supply with the supplied power cord.

TV

OPTICAL

~AC IN   OPTICAL

USB   AUX   OPTICAL   AC IN

4b AUX

Connect the Sound Bar with your TV through AUX cable (not supplied).

Connect the Sound Bar to the power supply with the supplied power cord.

TV

Headphone

~AC IN   AUX

USB   AUX   OPTICAL   AC IN

5a | Install or replace the remote batteries

Battery type: 1.5V AAA Alkaline battery x 2

❶ ❷ ❸ ❹

5b | Using the Remote

⏻
Short press: Power off
Long Press: Factory default

▶ll / l◀ / ▶l
Play/pause/resume playback
in Bluetooth/USB mode
Next in Bluetooth/USB mode
Previous in Bluetooth/USB mode

⊡
Source input

MOVIE / MUSIC / TV
Press to select the equalizer (EQ)
among MOVIE, MUSIC, TV.

🔇
Mute/Unmute

+ / −
Volume+/-

✳
Press and hold to activate
the pairing function in Bluetooth
mode or disconnect the paired device.

TCL

6 | Pair with your Bluetooth device

You can stream music from your mobile device via Bluetooth.

1. Press ⏻ .
2. Press ✳ on the remote control.
3. Press and hold ✳ or ▶|| on the remote control.
> You hear a sound signal and blue light is flashing on the sound bar.
> You will hear a sound and see a blue light flashing on the sound bar, indicating that it is ready to pair.
4. Power on your Bluetooth device and activate its Bluetooth function.
5. Select **TCL Alto 3**.
> You hear a sound signal.
> You will hear a sound indicating that the pairing is successful.
6. If you want to re-pair with another device, please repeat step 3.

TCL Alto 3

7 | Sound Bar LED Display

The LED display on the Sound Bar gives you information about the status of Sound Bar.

Sound Bar status	LED Indications
In standby mode	Red
In AUX mode	Green
In Bluetooth mode	Blue
In OPT mode	Yellow
In USB mode	Cyan
MOVIE	White LED flashes once
MUSIC	Green LED flashes once
TV	Yellow LED flashes once
⊠ Mute	Red LED keeps flashing

FAQ

Does this Sound Bar work with any TV?

Yes, the Sound Bar is compatible with any TV that has one of the ports below:

1. Optical audio output (TOSLink)
2. Headphone output

When the Sound Bar and TV are both on, there is an echo effect.

If using optical or AUX connection, simply mute the TV speaker.

How many sound modes are available?

Three sound modes - Movie, Music, and TV.

How to clean the Sound Bar?

Please keep your Sound Bar in a dry and ventilated environment. If it needs to be cleaned, please wipe it gently with a soft, dry cloth without water or other cleaning agents.

DO NOT RETURN TO STORE

WE ARE READY TO HELP

contact us first with any questions

TCL SUPPORT:
support.tclusa.com **or**
support.tclcanada.com
1-877-300-9223

⚠ TAKE CARE WHEN REMOVING THE SOUND BAR

❈ Bluetooth®

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by TTE Corporation is under license. Other trademarks and trade names are those of their respective owners.

▶◀ Dolby Audio

Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

TS3100_NA_QSG_V1.2